









Telephone User Instructions










Contents

Contents

1. Key Panel.....	3
1. Making and Receiving calls	5
1.1 Incoming calls	5
1.2 Outgoing calls	5
1.3 Re-dial 	5
1.4 Callers List	5
1.5 Internal calls (and call pickup)	5
1.6 Call Transfer.....	6
1.7 Call Forward.....	6
1.8 Hold 	7
2. DND – Do not Disturb.....	7
3. Ringer volume 	7
4. Loud Speaker 	7
5. Mute 	8
6. Voicemail.....	8
6.1 New Voicemail.....	8
6.2 Personalise Voicemail	8
7. Ringtone.....	9
8. Fault Reporting	9

1. Key Panel



<u>Keys</u>	<u>Key Description</u>
	Goodbye key - Ends an active call. The Goodbye key also exits an open list, such as the Options List, without saving changes.
	Options key - Accesses services and options to customize your phone. Your System Administrator may have already customized some of your settings. Check with your System Administrator before changing the administrator-only options.
	Hold key - Places an active call on hold. To retrieve a held call, press the call appearance button beside the light that is flashing.
	Redial key - Redials up to 100 previously dialed numbers. Pressing the Redial key twice redials the last dialed number.
	Volume control key - Adjusts the volume for the handset, ringer, and hands free speaker.
	Navigation keys - Pressing the UP and DOWN arrow keys lets you view different status and text messages on the LCD display (if there is more than 1 line of status/ text messages). These buttons also let you scroll through menu selections, such as the Options List. Pressing the LEFT and RIGHT arrow keys lets you view the different line/call appearances. While in the Options List, these keys allow you to exit or enter the current option. When you are editing entries on the display, pressing the LEFT arrow key erases the character on the left; pressing the RIGHT arrow key sets the option.
	Line/Call Appearance keys - Connect you to a line or call.
	Handsfree key - Activates Handsfree for making and receiving calls without lifting the handset. When the audio mode option is set, this key is used to switch between a headset and the handsfree speakerphone.
	Mute - mute the handset, headset, or speakerphone. When you use the mute key on your phone, you cannot be heard on an active call or on a conference.

1. Making and Receiving calls

1.1 Incoming calls

All incoming calls will be routed as guided by management. To answer a call either lift the handset or press the speaker key to answer the call hands free.

1.2 Outgoing calls

A call can be made either by lifting the handset or hands free.

Handset – Lift the handset. Enter the number to dial, followed by the right navigation key (as prompted on the phone display).

Hands free – Enter the number to dial, then press the speaker key.

The area code must be dialled for local calls.

1.3 Re-dial



The phones will store the last 100 numbers dialled. Press the re-dial key to display the last numbers you called on the display. Press re-dial again to make the call. You can use the navigation keys to select the number to re-dial.

The re-dial list is also available during an active call.

1.4 Callers List

The phones will store the last 200 calls that have been received. Press the callers list key at the top of the phone, then scroll up and down to view the call history using the navigation keys.

If the handset is off hook, press L1 to make the call.

To make a call on hook either lift the handset or press L1.

1.5 Internal calls (and call pickup)

All extensions can be dialled internally by dialling the extension number. If another extension is ringing this can be picked up by dialling *8 from another phone.

1.6 Call Transfer

To transfer a call to another extension (or external number) follow these steps:

- Press the transfer key at the top of the phone. You should hear dial tone as the second line opened up.
- Dial the extension number (or outside number).
- You are then connected to the new extension and the customer will hear hold music. You can now introduce the call.
- To complete a blind transfer press the Transfer key again before the receiving end answers. To complete an attended transfer remain on the line to speak to party 2 before pressing the transfer key.
- Both parties are now connected.

If the person you are transferring too is not available you can pull back the call by press the flashing Line light (probably L1).

1.7 Call Forward

Turn on:

- Press the options key
- Scroll down using the down navigation key and select 'call forward' the press Enter
- Select a Call Forward mode to set on the account (**All, Busy, No Answer, All On, All Off**) and
- press **Change**
- Using the **DOWN** arrow key, scroll to the **CFWD State** you want to set and press **Change**.
- Using the **DOWN** arrow key, toggle the state ON or OFF as required and press **Set**.
- Press the **DOWN** arrow key to scroll to **CFWD Number** and press Change.
- Enter the call forward phone number for the state you are configuring and press **Set**.
- (**No Answer state**) If you enable the "No Answer" state, in addition to entering a phone number, you must also specify the number of rings for your phone.

Using the **DOWN** arrow key, scroll to **No. Rings** and press **Change**. Use the **UP** and **DOWN** arrow keys to select the number of rings you want your phone to perform before forwarding

any incoming calls. Valid values are **1** through **9**. Default is **1**.

- Press **Done** and then press **#** to confirm the change

1.8 Hold



You can place a call on hold by pressing the hold key. When you place a call on hold only your phone can retrieve the call.

To retrieve the call, press the hold key again.

To place a second call while someone is on hold press another Line key. Eg L2. You can then swap between active calls by pressing the corresponding Line Key.

2. DND – Do not Disturb

To enable the DND function, press the DND key at the top of the phone. Pressing it again toggles DND on and off.

If DND is turned on the screen displays “DND Activated” and the light will be on for the DND button.

3. Ringer volume



The ringer volume can be increased and decreased by pressing the loud speaker icons at the bottom of the phone. Bottom right to increase and bottom left to decrease.

4. Loud Speaker



You can transfer a call between the handset and loudspeaker (hands free) by pressing the green speaker key. To change the call back to the phone handset, press the speaker key again to toggle back.

5. Mute



A call can be put on mute by pressing the microphone button at the bottom of the phone keypad. This will enable you to hear the customer but they will not be able to hear you.

6. Voicemail

6.1 New Voicemail

If a voicemail is received it will be displayed on the phone and will inform you how many messages there are in your inbox. All extensions have voicemail.

If a voicemail has been received:

- Dial *97 then the right navigation key
- You will be prompted for your password
- Enter the password (which is the reverse of the extension number).

You can access your voicemail from any other extension:

- Dial *98 then the right navigation key
- You will be prompted for your mailbox
- Enter your extension number
- You will then be prompted for your password
- Enter your password (the reverse of your extension number)
-

Follow the audio prompts for options.

6.2 Personalise Voicemail

You can personalise the voicemail message by following these menu options:

- Login to voicemail as above
- Then press 0 for mailbox options.
- Then press 1 to record your unavailable message.
- After the tone say your unavailable message and then press the # key.
- Follow the prompts to save, listen to your message, or re-record your message.

7. Ringtone



- .To change the ringtone of the phone press the options key for information.
- Scroll down to Preferences and press Enter..
- Select Tones and press Enter
- Select Ring Tone and press Enter
- Press the down navigation key to scroll through the different ringtones available.
- Press “set” when you have chosen your ringtone.
- Press the red goodbye key to go back to the main menu.

8. Fault Reporting

In the event of a fault call support on 01684 878060 or report via web ticketing system <http://support.northway.net>